



C/ Santa Anna nº 5
03801 Alcoy (Alicante) Spain
tel. 606963128 and
650782761
<http://www.primlab.com/>



ART. 100/051

TECHNICAL DATA SHEET REUSABLE HYGIENIC MASK WITH FILTER

Description:	Black mask reused with 3-layer filter
Composition:	ART: 100/051. Black color, 80% Polyester, 20% Elastane, width 1.60 and additive with CO2pure (mineral additive) + ESTAMPLUS DUOSP filter 1:00 DIG BLACK with 3 layers 100% black pes and 1 layer 70% pes and 30% vis of 60 gr
Grammage:	180 gr-190 gr

DESCRIPTION CHARACTERISTICS FABRIC

CHARACTERISTICS	SPECIFICATION	METHOD
Composition. Tissue	80%Polyester 20% Elastan Filter ESTAMPLUS DUOSP	ISO 1833
Total Weight g / m2:	270 g / m2	EN 12127
Fabric construction		BS 5441
Elastic rubber composition	83% Polyester - 17% Elastane	ISO 1833
Bacterial Filtration Efficiency (BFE) (%) (Original > 90)	91.71	EN 14683: 2019 + AC: 2019
Breathability: Differential pressure (Pa / cm2) (Original <60)	32.6	EN 14683: 2019 + AC: 2019
Bacterial Filtration Efficiency (BFE) (%) (after 25 washes > 90)	70.29	EN 14683: 2019 + AC: 2019
Breathability: Differential pressure (Pa/cm2) (after 25 washes <60)	28.6	EN 14683: 2019 + AC: 2019
Report number (Aitex):	2020TM4420	
CO2pure antiviral activity	CO2pure 8%	EN 14476

UNE 0065: 2020 specification. Reusable hygienic masks for adults and children. Requirements for materials, design, preparation, marking and use.

PACKAGE DESCRIPTION

Size	Adults	Colour	Black	Quantity:	Adjustable with elastic rubber bands
------	--------	--------	-------	-----------	--------------------------------------

Expiration date: 5 years from the date of manufacture

"WARNING: This device is not a medical device in the sense of Directive 93/42 of Regulation EU/2017/745, nor an individual protection equipment in the sense of Regulation EU / 2016/425".

Installation instructions:



Instructions for use:

- Wash your hands with soap and water.
- Identify the upper part of the mask with the twist band.
- Position the mask on the face, hold the mask from the outside.
- Lower the lower part of the mask to the chin and adjust the twist band to the nose.
- To remove the mask, wash your hands with soap and water, remove the mask without touching the front.

Washing conditions:

- Immerse the masks in a 1:50 bleach dilution with warm water for 30 min. Then wash with soap and water and rinse well to remove any residual bleach and allow to dry.

